

Image, Video, and Data Files

* HighGUI: Portable Graphics Toolkit

- "high-level graphical user interface"
- Interact with OS, the file system and hardware such as Camera.
- Read and write graphics-related files (Images & Video)
- Open and manage windows, to display images,
 - ↳ Handle simple mouse pointer and keyboard event.

⇒ HighGUI library in OpenCV can be divided into three parts:

- ↳ Hardware part (Operation of cameras)
- ↳ file system part
- ↳ GUI part:

* Working with Image file

⇒ Functions here deals, with the complexities associated with compressing and decompressing the image data.

* Loading and Saving Images

⇒ The easiest way to do this is with the high-level functions `cv::imread()` and `cv::imwrite()`.

* Reading a file with cv::imread()

cv::Mat cv::imread(
const string& filename,
int flags = CV_IMREAD_COLOR
);

} determination of cv::imread()

⇒ When opening an image, cv::imread() doesn't look at the file extension.

↳ Instead, it analyzes the first few bytes of the file (a.k.a signature) and determines the appropriate codec using it.

Table 8.1

→ All the flags

CV_IMREAD_COLOR
(Default)

⇒ cv::imread() does not give a runtime error when it fails to load an image.

↳ It simply returns empty cv::Mat.

* Writing a file with cv::imwrite()

bool cv::imwrite (

const String filename,

cv::InputArray image,

const Vector<int> params = Vector<int>()

);

⇒ The first argument gives the filename, whose extension is used to determine the format in which the file will be stored.

Example: of some popular extensions supported by OpenCV.

.jpg , .jpeg , .png etc

⇒ The second argument is the image to be stored.

Codecs

→ { Compression and Decompression Libraries }

* Reading Video with the cv::VideoCapture Object

⇒ cv::VideoCapture object contains the information needed for reading frame from a camera or video file.

⇒ Depending on the source, we use one of three different calls to create a `cv::VideoCapture` object.

① `cv::VideoCapture::VideoCapture(
const string& filename,
);`

② `cv::VideoCapture::VideoCapture(
int device
);`

③ `cv::VideoCapture::VideoCapture();`

⇒ If the open is successful and we are able to start reading frames, the member function `cv::VideoCapture::isOpened()` will return `true`.

⇒ As with the image codecs, you will need to have the appropriate libraries already residing on your computer in order to successfully read the video file.

⇒ If you use 3rd construction then you need to call `cv::VideoCapture::Open()`.

Example

```
cap.open("my_video.avi");
```

* Reading Frames with cv::VideoCapture::read()

```
bool cv::VideoCapture::read(  
    cv::OutputArray image  
);
```

↳ { this will get the next frame }

⇒ This action will automatically "advance" the video capture object such that a subsequent call to `cv::VideoCapture::read()` will return the next frame and so on.

⇒ If the read was not successful, then this function will return false (otherwise it will return true).

* Reading Frames with cv::VideoCapture ::operator >> ()

⇒ Behaves exactly the same as `cv::VideoCapture::read()`, except that it returns reference to the original `cv::VideoCapture` object regardless of whether it succeeded.

↳ In this case, you must check that the return array is not empty.

★ Reading frames with cv::VideoCapture::grab and cv::VideoCapture::retrieve()

⇒ There are many reasons to grab and retrieve separately rather than together as would be the case in calling cv::VideoCapture::read().

Example: When there are multiple cameras
(Stereo imaging)

★ Camera properties: cv::VideoCapture::get() and cv::VideoCapture::set()

⇒ Video file contains not only video frames themselves, but also important meta-data, which can be essential for handling the files correctly.

Table 8.4 → { List of Video Capture Properties }

★ Writing Video with the cv::VideoWriter object

⇒ We need to create cv::VideoWriter object before we can write out our video.


```

cv::VideoWriter::VideoWriter(
    const string& filename,
    int fourcc,
    double fps,
    cv::Size frame-size,
    bool is-color = true
);

```

Example

```

cv::VideoWriter out;

```

```

out.open(

```

```

    "my-video.mp4",

```

```

    CV_FOURCC('D','I','V','X'),

```

```

    30.0,

```

```

    cv::Size(640, 480),

```

```

    true

```

```

);

```

⇒ cv::VideoWriter::isOpened() method, which will return true if you are good to go.

* Writing frames with cv::VideoWriter::write()

```

cv::VideoWriter::write(

```

```

    const Mat& image

```

```

);

```

* Writing frames with cv::VideoWriter
operator <<()

my-video-writer << my-frame

* Data Persistence

⇒ The basic mechanism for reading and writing files is the cv::FileStorage object.

* Writing to a cv::FileStorage

FileStorage::FileStorage(String FileName, int flag);

⇒ The cv::FileStorage object is a representation of an XML or YAML data file.

FileStorage::FileStorage();

cv::FileStorage::Open();

flag → cv::FileStorage::WRITE
→ cv::FileStorage::APPEND

⇒ Data inside cv::FileStorage is stored in one of two forms, either as a "mapping" or a "sequence".

↳ At the top level, the data you write to the file storage is all mapping and inside of that you can place other mappings or sequences.

⇒ Once you are completely done writing, you close the file with the `cv::FileStorage::release()` member function.

* Reading from a `cv::FileStorage`

⇒ The `cv::FileStorage` object can be opened for reading the same way it is opened for writing except that the flag argument should be set to `cv::FileStorage::READ`.

⇒ The data can be read using overloaded array operator `cv::FileStorage::operator[]()`.

→ We need to pass the string key
→ Returned object is of type `cv::FileNode`.

* `cv::FileNode`

⇒ If it represents an object, you can just load it into a variable of the appropriate type with the overloaded extraction operator `cv::FileNode::operator>>()`.

Example

```
int num;  
myFileStorage["SumInteger"] >> num;
```

