

Sensor_msgs/CameraInfo

⇒ This message defines meta information for a camera.

⇒ It should be in a camera namespace on topic "camera_info".

⇒ It is accompanied by up to five image topics named:

1. image_raw - raw data from the camera driver, possibly Bayer encoded
2. image - monochrome, distorted
3. image_color - color, distorted
4. image_rect - monochrome, rectified
5. image_rect_color - color, rectified

⇒ The image_geometry package provides a user-friendly interface to common operations using this meta information.

⇒ If the camera is uncalibrated, the matrices D, K, R, P should be left zeroed out.

```
std_msgs/Header header
uint32 height
uint32 width
string distortion_model
float64[] D
float64[9] K
float64[9] R
float64[12] P
uint32 binning_x
uint32 binning_y
sensor_msgs/RegionOfInterest roi
```

Data in the message

0.00391	0	-0.03516	-0.03125	-0.03516	0	0.00391
0	0	0	0	0	0	0
-0.03516	0	0.31641	0.28125	0.31641	0	-0.03516
-0.03125	0	0.28125	1.00000	0.28125	0	-0.03125
-0.03516	0	0.31641	0.28125	0.31641	0	-0.03516
0	0	0	0	0	0	0
0.00391	0	-0.03516	-0.03125	-0.03516	0	0.00391

1. Header


- Time of image acquisition
- Camera coordinate frame ID
- sequence ID: consecutively increasing ID

origin of frame should be optical center of camera
+x should point to the right in the image
+y should point down in the image
+z should point into the plane of the image

2. height and width

→ Number of pixel in the image in x-direction

→ Number of pixel in the image in y-direction.



3. distortion model

→ Name of distortion model used.

{ Most Common }

plumb_bob

rational_polynomial

{ Presently supported distortion model }

4. D

- The distortion parameters, size depending on the distortion model.
- For "plumb_bob", the 5 parameters are: (k1, k2, t1, t2, k3).

5. K

- Intrinsic camera matrix for the raw (distorted) images.
- $$K = \begin{bmatrix} f_x & 0 & c_x \\ 0 & f_y & c_y \\ 0 & 0 & 1 \end{bmatrix}$$
 - focal lengths (fx, fy)
 - principal point (cx, cy)
- Projects 3D points in the camera coordinate frame to 2D pixel coordinates.

6. R

Rectification matrix (stereo cameras only)

- A rotation matrix aligning the camera coordinate system to the ideal stereo image plane so that epipolar lines in both stereo images are parallel.

7. P

- Projection/camera matrix

$$P = \begin{bmatrix} f_x' & 0 & c_x' & T_x \\ 0 & f_y' & c_y' & T_y \\ 0 & 0 & 1 & 0 \end{bmatrix}$$
- By convention, this matrix specifies the intrinsic (camera) matrix of the processed (rectified) image.
- Focal lengths (fx', fy') and principal point (cx', cy'), may differ from the values in K.
- For monocular cameras, $T_x = T_y = 0$.
- Normally, monocular cameras will also have $R = \text{the identity}$ and $P[1:3, 1:3] = K$.
- For a stereo pair, the fourth column $[T_x \ T_y \ 0]'$ is related to the position of the optical center of the second camera in the first camera's frame.
 - We assume $T_z = 0$ so both cameras are in the same stereo image plane.
- The first camera always has $T_x = T_y = 0$.
For the right (second) camera of a horizontal stereo pair, $T_y = 0$ and $T_x = -f_x' * B$, where B is the baseline between the cameras

8. binning_x and binning_y

- It reduces the resolution of the output image to $(\text{width} / \text{binning_x}) * (\text{height} / \text{binning_y})$.
- The default values $\text{binning_x} = \text{binning_y} = 0$ is considered the same as $\text{binning_x} = \text{binning_y} = 1$ (no subsampling).

9. Region of Interest

Subwindow of full camera resolution.

The default setting of roi (all values 0) is considered the same as full resolution ($\text{roi.width} = \text{width}$, $\text{roi.height} = \text{height}$).

- `uint32 x_offset` → Leftmost pixel of the ROI
- `uint32 y_offset` → Topmost pixel of the ROI
- `uint32 height` → Height of ROI
- `uint32 width` → Width of ROI
- `bool do_rectify` → Typically this should be False if the full image is captured (ROI not used), and True if a subwindow is captured (ROI used).

